




Tv Unit



Up to 60 minutes
assembly time



Two person
assembly



Electric screwdriver
prohibited

This product is intended for domestic use only, not for commercial purposes.

Important

Before you begin

Before you begin, we advise laying everything out on a clean and soft level surface to avoid damaging the unit or your floor. It's best to identify all of the parts and fittings to build your tv unit, and to familiarise yourself with all of the parts and fittings before building.

Top Tip

We recommend that you build your new tv unit in the room you'd like it to be located. This will help prevent any risk of damage to the product from moving it.

Safety and Care

1. It's important to ensure small components used in this tv unit are kept away from the assembly area, as there are small components and fittings which could present a choking hazard.
2. All plastic and wrapping materials should also be kept away from children and animals. Do not stand on your product.
3. Always have the item on firm level ground, ensuring all legs remain in contact with the ground.
4. Place heaviest items in the lowest drawers
5. Do not set TV or other heavy objects on top of the product. Never allow children or pets to climb or play on the product.
6. Children should always be under supervision while using this product. Never allow children to climb on the drawers.
7. Never keep more than one drawer open at the same time.
8. The installation of anti-tipping kits to secure your furniture is strongly suggested.
9. Serious risk of crushing or trapping in a drawer from tipping furniture.

Help and Support

Please contact our customer service team on 0113 519 0311 if you have any questions or issues with your purchase.


Recycling

Please ensure that packaging is disposed of in a safe and environmentally friendly way, and recycled where possible. Please keep your assembly instructions safe to refer back to in the future.

Care and Maintenance

1. Only clean using a damp cloth, do not use bleach or abrasive cleaners as they may damage the finish over time.
2. Do not scrub or rub the cloth or allow any liquid to contact with the veneer for a long period of time.
3. Do not use a wet cloth to wipe when cleaning.
4. To move the tv unit immediately. Absorption can cause the wood to warp or finishes to lose a pleasant.
5. Use a placemat or a coaster when putting hot items (e.g. hot drinks and dishes) on the wood surface.
6. It is not recommended to place the item next to sources of heat such as radiators, fires or directly exposed to sunlight. This may cause the wood to crack, split or fade due to the change of wood humidity and temperature.
7. The wood will mellow and change colour over time, we recommend that ornaments and items placed on the surface to be moved regularly to prevent uneven mellowing.
8. Regularly check all fixings to ensure they have not become loose. Re-tighten if necessary.
9. Avoid sharp items such as a screwdriver or any pointy tools.

Parts list






Parts list

Before you begin building your tv unit, please take a moment to read through the instructions and make sure that you have all the relevant parts listed on the parts check list.


Part Number	Part Description	Quantity	Box No
1	Top Panel	1 pc	Box 1
2	Left side plate	1 pc	Box 1
3	Middle panel	1 pc	Box 1
4	Middle panel	1 pc	Box 1
5	Right side plate	1 pc	Box 1
6	Bottom Panel	1 pc	Box 1
7	Back Panel	2 pcs	Box 1
8	Back Panel	1 pc	Box 1
9	Fixed layer plate	1 pc	Box 1
10	Support foot	2 pcs	Box 1
11	Door	1 pc	Box 1
12	Door	1 pc	Box 1

Fittings Checklist

Please check you have all the fittings listed below with your product in Box 1.

<p>A</p>  <p>M6x35mm Cam Bolt x16 pcs(+2 extra)</p>	<p>B</p>  <p>Ø15x9mm Cam Lock x16pcs(+2 extra)</p>	<p>C</p>  <p>Ø8x30mm Wood Dowel x20pcs(+2 extra)</p>
<p>D</p>  <p>M4x40mm Screw x4pcs</p>	<p>E</p>  <p>Door Strike Plate x2pcs</p>	<p>F</p>  <p>Plastic Buckle x12pcs(+2 extra)</p>
<p>G</p>  <p>M3x14mm Screw x40pcs(+4 extra)</p>	<p>H</p>  <p>Hinge x4pcs</p>	<p>I</p>  <p>Cover x8pcs(+1 extra)</p>
<p>J</p>  <p>Door Catch x2pcs</p>	<p>K</p>  <p>Handle x2pcs</p>	<p>L</p>  <p>M4x18mm Bolt x4pcs</p>
<p>M</p>  <p>M3x12mm Screw x4pcs</p>	<p>N</p>  <p>Screwdriver x1pc</p>	




Bolt Length Ruler:






Tool required





Step 1: Install the eccentric rod A onto panels 2&3&4&5.





Step 2: Connect panels 2 and 5 to panel 6 with wooden tenon C, and then turn eccentric wheel B clockwise to tighten.




Step 3: Connect panels 3 and 4 to panel 9 with wooden tenon C, and then turn eccentric wheel B clockwise to tighten.




Step 4: Connect panels 3 and 4 to panel 6 with wooden tenons C, and then fix them with screws D



Step 5: Fix the Leg 10 to the panel 6.




Step 6: Insert the back plate 7&8 into the slot and then place the wooden tenon C.




Step 7: Install the eccentric rod A onto panels 1.
Fix the door latch J to the panel 1 with screw G.

A		8pcs
J		2pcs
G		4pcs




Step 8: Connect Panel 1 to the assembled panel,
then insert the eccentric wheel B and tighten it clockwise,
and stick on the hole sticker I.

B		8pcs
I		8pcs




Step 9: Reinforce back plate 7&8 using part(F) with screw(G) as shown.

(F)		12pcs
(G)		12pcs




Step 10: Connect the hinges to Door 11 and Door 12.

(H)		4pcs	(L)		4pcs	(M)		4pcs
(G)		12pcs	(K)		2pcs	(E)		2pcs



Step 11: Install the door on panels 2&5.



Step 12: The installation is complete.

