

DUSK.COM

Range Name: Avani


Box dimensions: W185 x D76 x H53 (cm)

Sofa dimensions: W182 x D91 x H73 (cm)

Sofa bed dimensions: W182 x D137.5 x H38 (cm)

LIVING | BEDROOM | DINING


Avani Sofa Bed



THIS INSTRUCTION BOOKLET CONTAINS IMPORTANT SAFETY INFORMATION.
PLEASE READ AND KEEP FOR FUTURE REFERENCE.



20 minutes approx
assembly time



Two adults
assembly required

This product is intended for domestic use only, not for commercial purposes.

IMPORTANT

ASSEMBLY TIP

Before you begin, it's best to identify all of the parts and fittings to build your sofa frame. We advise laying these out on the floor to check you have everything, and to familiarise yourself with all of the parts and fittings before building.

TOP TIP

We recommend that you assemble the sofa in the room you'd like it to be located. This will help prevent any risk of damage to the frame whilst moving it.

SAFETY AND CARE

It's important to ensure children and animals are kept away from the assembly area, as there are small components used in this product which could present a choking hazard. All plastic and wrapping materials should also be kept away from children and animals to prevent any risk of suffocation.

HELP AND SUPPORT

Please contact our customer service team on 0113 519 0311 if you have any questions or issues with your purchase.

RECYCLING

Please ensure that packaging is disposed of in a safe and environmentally friendly way, and recycle where possible. Please keep your assembly instructions safe to refer back to in the future.


CARE AND MAINTENANCE

1. Clean with your vacuum curtain attachment (the one with a lint-catching fabric strip) or a lint roller to stop dust build up. Do this regularly to keep the sofa in its best condition.
2. Regularly plump the backrest pillows by shaking and squeezing to even out the filling.
3. Try to keep your sofa away from direct sunlight, and not too close to heat sources, as this can cause fading over time. Do not allow the sofa to make direct contact with any radiators or sources of heat.
4. Wipe up the spillages as quickly as possible by gently dabbing or blotting with a dry cloth until the mark fades away. Some tougher spills, such as oil and grease, can be more persistent and leave a stain. In this case, it's best to contact a specialist cleaning service.
5. Do not drag the sofa. When moving, lift the sofa off the floor.
6. Keep children and pets away from the assembly area and any packaging, small parts could choke is swallowed.
7. Do not sit on the arms of the sofa.
8. Do not jump on the sofa.
9. Only use the sofa on a flat and level surface.
10. Dispose of all packaging carefully and responsibly - recycle where possible.
11. Avoid sharp items such as toys, jean rivets, buckles etc
12. For quicker restoration, a garment steamer can be used to gently remove creases and marks for items in velvet fabric.

Parts checklist

Please check you have all the parts listed below with your product:




Do not discard any of the packaging until you have checked that you have all the parts and the pack of fixings.






NO.	Parts List	QTY
1	Frame	1PC
2	storage bottom frame	1PC
3	Back frame	1PC
4	Back pillow	2PCS
5	Arm pillow	2PCS

Fittings checklist


Please check you have all the fittings listed below with your product:

A	B	C	D	E	F
					
Leg Ø45x40mm	Middle leg Ø40x35mm	Bolt M6x15mm	screw M4x35mm	M8 Washer	M5 Allen key
6PCS	1PC	1PC	15PCS+2extra	1PC	1PC


Pre-attached fittings

					
Hinge 110x50x2.0mm	Leg Ø30x210mm	Leg Ø40x20mm	Wheel 20x10x18mm	Plastic Gasket Ø18x22mm	Bolt M8x70mm
3PCS	1PC	2PCS	3PCS	4PCS	2PCS
					
screw M4x35mm	screw M4x20mm				
21PCS	6PCS				



Step 1 Remove back cushions, arm cushions and hardware from the storage box.





Step 2 Secure the backrest to the top of the storage box with the supplied bolts.




Step 3 Secure the front legs and rear legs as shown in the above picture.




Step 4 Secure the middle support leg with the supplied bolts as shown in the above picture.




Step 5 Secure the front legs as shown in the above picture.




Step 6 Place the seat frame on top of the storage box as shown in the above picture.



Step 7 Flip backrest sections to switch to sofa bed mode, see drawing above.




Step 8 Turn support feet to adjust height for level frame, see above diagram.



The support leg is tightly constructed with stiff resistance on first unfolding. Pull firmly outwards with both hands until fully opened and locked.

Step 9 Flip backrest upward, lift seat cushions 5cm and slide inward to restore sofa shape, see drawing above.



Step 10 Finished.

