




Heidi Display Cabinet



Up to 60 minutes
assembly time



Two person
assembly



Electric screwdriver
prohibited

IMPORTANT

ASSEMBLY TIP

Before you begin, we recommend laying everything out on a clean and soft level surface to avoid damaging the unit or floor. It is recommended to identify all of the parts and fittings to build your Display Cabinet and to familiarise yourself with all of the parts before assembly.

TOP TIP

We recommend that you assemble the Display Cabinet in the room you'd like it to be located. This will help prevent any risk of damage to the frame whilst moving it.

SAFETY AND CARE

1. It is important to ensure children and animals are kept away from the assembly area, as there are small components used in this product which could present a choking hazard. All plastic and wrapping materials should also be kept away from children and animals to prevent any risk of suffocation.
2. Do not stand on your product.
3. Always use the item on firm level ground, ensuring all legs remain in contact with the ground.
4. Place heaviest items in the lowest cupboards and shelf.
5. Do not set TV or other heavy objects on top of the product.
6. Children should always be under supervision whilst using this product. Never allow children to climb on the cabinet.
7. In order to prevent overturning, this product must be used with the wall attachment device provided.
8. Serious or fatal crushing injuries can occur from tipping furniture.

HELP AND SUPPORT

Please contact our customer service team on 0113 519 0311 if you have any questions or issues with your purchase.

RECYCLING

Please ensure that packaging is disposed of in a safe and environmentally friendly way, and recycle where possible. Please keep your assembly instructions safe to refer back to in the future.

CARE AND MAINTENANCE


1. Only clean using a damp cloth, do not use bleach or abrasive cleaners as they may damage the finish over time.
2. Do not use a very wet cloth or allow any liquid to contact with the surface for a long period of time. Wipe any spillage immediately. Absorption can cause wood to warp or finishes to de-laminate.
3. Do not scrub or rub the surface when cleaning.
4. Do not drag the display cabinet when moving, lift it off the floor instead.
5. Use a placemat or a coaster when putting hot items (e.g. hot drinks and dishes) on the wood surface.
6. It is not recommended to place the item next to sources of heat such as radiators, fires or directly exposed to sunlight. This may cause the wood to crack, split or fade due to the heat and humidity.
7. Wood will mellow and change colour over time, we recommend that ornaments and items placed on the surface are moved regularly to prevent uneven mellowing.
8. Regularly check all fixings to ensure none have come loose. Re-tighten if necessary.
9. Avoid sharp items such as a screwdriver or any pointy tools.

Parts list

Before you start to build your Heidi Display Cabinet, please take a moment to read through the instructions and make sure that you have all the relevant parts listed on the parts checklist.














Part Number	Part Description	Quantity
1	Left Side Frame	1 pc
2	Right Side Frame	1 pc
3	Top Panel	1 pc
4	Middle Panel	1 pc
5	Middle Panel	1 pc
6	Middle Panel	1 pc

Part Number	Part Description	Quantity
7	Bottom Panel	1 pc
8	Back Support Strip	3 pcs
9	Back Support Strip	1 pc
10	Back Panel	1 pc
11	Door	2 pcs









Fittings

Please check you have all the fittings listed below with your product.



1. Attach parts to the Panels.




C	
Ø8x30mm Dowels	
22pcs	

E	
Magnetic Door Catch	
4pcs	

G	
M3x15mm Screw	
8pcs	





2. Attach parts to Back Support Strips and Side Frames.



A	
	M6x40 CAM Lock Screws
	40pcs

C	
	$\varnothing 8 \times 30\text{mm}$ Dowel
	8pcs


3. Attach the Panels to Back Support Strips.




B	
Ø15x11.5mm CAM Locks	12pcs

D	
Covers	12pcs


4. Attach Panels and Back Support Strips to Right Side Frame.




5. Attach Left Side Frame to Panels.









6 Attach the cam locks and covers










7. Assemble Back Panel and Anti Fall Straps to the Frames



8. Attach parts to the Doors.



9. Attach the Doors to the Frame.



WARNING: This furniture should be securely attached to the wall using the straps provided.
Please check your own wall to ascertain the correct fixings required (not supplied).

