

DUSK.COM


LIVING | BEDROOM | DINING

Range Name : Heidi


Box Dimensions: W110xD46xH12cm

Product Dimension : W100xD35xH80cm

Heidi Console Table



Up to 30 minutes
assembly time



One person
assembly



Electric screwdriver
prohibited

This product is intended for domestic use only, not for commercial purposes.

V-1.0

P-1-5

IMPORTANT

ASSEMBLY TIP

Before you begin, we recommend laying everything out on a clean and soft level surface to avoid damaging the unit or floor. It is recommended to identify all of the parts and fittings to build your table and to familiarise yourself with all of the parts and fittings before assembly.

TOP TIP

We recommend that you assemble the console table in the room you'd like it to be located. This will help prevent the chance of damaging the item when moving it.

SAFETY AND CARE

1. It is important to ensure children and animals are kept away from the assembly area, as there are small components used in this product which could present a choking hazard. All plastic and wrapping materials should also be kept away from children and animals to prevent any risk of suffocation.
2. Do not stand on your product. Pregnant women should take additional care when using this product. Do not leave children unattended. Children should always be under direct adult supervision whilst using this product.
3. Always use on firm level ground, ensuring all legs remain in contact with the ground.
4. Do not set TV or other heavy objects on top of the product.
5. Children should always be under supervision whilst using this product. Never allow children to climb on the table.

HELP AND SUPPORT

Please contact our customer service team on 0113 519 0311 if you have any questions or issues with your purchase.

RECYCLING



Please ensure that packaging is disposed of in a safe and environmentally friendly way, and recycle where possible. Please keep your assembly instructions safe to refer back to in the future.

CARE AND MAINTENANCE

1. Only clean using a damp cloth, do not use bleach or abrasive cleaners as they may damage the finish over time.
2. Do not use a very wet cloth or allow any liquid to contact with the veneer for a long period of time. Wipe any spillage immediately. Absorption can cause wood to warp or finishes to de-laminate.
3. Do not scrub or rub the surface when cleaning.
4. Do not drag the console table when moving, lift it off the floor instead.
5. Use a placemat or a coaster when putting hot items (e.g. hot drinks and dishes) on the wood surface.
6. It is not recommended to place the item next to sources of heat such as radiators, fires or directly exposed to sunlight. This may cause the wood to crack, split or fade due to the change of the humidity and temperature.
7. Wood will mellow and change colour over time, we recommend that ornaments and items placed on the surface are moved regularly to prevent uneven mellowing.
8. Regularly check all fixings to ensure none have come loose. Re-tighten if necessary.
9. Avoid sharp items such as a screwdriver or any pointy tools.


Parts list

Before you start to build your Heidi Console Table, please take a moment to read through the instructions and make sure that you have all the relevant parts listed on the parts checklist.




Fittings list

Please check you have all the fittings listed below with your product.



Pre-assembled Fittings.



Bolt Length Ruler





Tool Required (not provided)



Step 1: Get the legs ready for assembly.

E  8 pcs

F  4 pcs



Step 2: Attaching the legs to the table top.

- A  8 pcs
- B  8 pcs
- C  8 pcs
- D  1 pc

