

DUSK.COM

Range Name : EVIE Box dimensions : 113x51x26.5cm

Evie Tall Chest







Up to 30 minutes assembly time

Two person assembly

This product is intended for domestic use only,not for commercial purposes.

IMPORTANT

ASSEMBLY TIP

Before you begin, it's best to identify all of the parts and fittings to build your Evie Tall Chest frame. We advise laying these out on the floor to check you have everything, and to familiarise yourself with all of the parts and fittings before building.

TOP TIP

We recommend that you assemble the Evie Tall Chest in the room you'd like it to be located. This will help prevent any risk of damage to the frame whilst moving it.

SAFETY AND CARE

It's important to ensure children and animals are kept away from the assembly area, as there are small components used in this product which could present a choking hazard. All plastic and wrapping materials should also be kept away from children and animals to prevent any risk of suffocation.

HELP AND SUPPORT

Please contact our customer service team on 0113 519 0311 if you have any questions or issues with your purchase.

RECYCLING

Please ensure that packaging is disposed of in a safe and environmentally friendly way, and recycle where possible. Please keep your assembly instructions safe to refer back to in the future.

CARE AND MAINTENANCE:

1. Only clean using a damp cloth, do not use bleach or abrasive cleaners as they may damage the finish over time.

2. Do not use a very wet cloth or allow any liquid to contact with the veneer for a long period of time. Wipe any spillage immediately. Absorption can cause wood to warp or finishes to de-laminate.

3.Do not scrub or rub the surface when cleaning.

4. Do not drag the Evie Tall Chest when moving, lift it off the floor instead.

5. Use a placemat or a coaster when putting hot items (e.g. hot drinks and dishes) on the wood surface.

6. It is not recommended to place the item next to sources of heat such as radiators, fires or directly exposed to sunlight. This may cause the wood to crack, split or fade due to the heat and humidity.

7. Wood will mellow and change colour over time, we recommend that ornaments and items placed on the surface to be moved regularly to prevent uneven mellowing.

8. Regularly check all fixings to ensure none have come loose. Re-tighten if necessary.

9. Avoid sharp items such as a screwdriver or any pointy tools.

10. Dispose of all packaging carefully and responsibly - recycle where possible.

Parts list


Before you begin building your Evie Tall Chest, please take a moment to read through the instructions and make surethat you have all the relevant parts listed on the parts check list.


Part Description	Quantity
Left Side Panel	1pc
Right Side Panel	1pc
Тор	1pc
Back Panel	1pc
Back slats	1pc
Leg	4pcs
Bottom Panel	1pc
Drawer Left Side	5pcs
Drawer Right Side	5pcs
Drawer Back Side	3pcs
Drawer Bottom	3pcs
	Left Side Panel Right Side Panel Top Back Panel Back slats Leg Bottom Panel Drawer Left Side Drawer Right Side


Part Number	Part Description	Quantity
12	Drawer Floor	3pcs
13	Left Drawer Front	1pc
14	Right Drawer Front	1pc
15	Drawer Front	3pcs
16	Back Panel	1pc
17	Drawer Back Side	2pcs
18	Drawer Bottom	2pcs
19	Middle Panel	1pc
20	Centre Support	1pc
21	Centre Support	2pcs


Fittings


Please check you have all the fittings listed below with your product.





























14.Manually adjust the frame slightly to ensure the drawers are in the correct position, even and parallel before attaching the plastic buckles.

