

DUSK.COM



LIVING | BEDROOM | DINING

Range Name : Hattie


Box1 dimensions : W192xD46.5xH19.5cm

Product Dimension:W180xD39xH56cm

Hattie Large Tv Unit



Up to 60 minutes
assembly time



Two person
assembly



Electric screwdriver
prohibited

This product is intended for domestic use only, not for commercial purposes.

P-1-15
V-1.0

IMPORTANT

ASSEMBLY TIP

Before you begin, it's best to identify all of the parts and fittings to build your the Hattie Large Tv Unit frame. We advise laying these out on the floor to check you have everything, and to familiarise yourself with all of the parts and fittings before building.

TOP TIP

We recommend that you assemble the Hattie Large Tv Unit in the room you'd like it to be located. This will help prevent any risk of damage to the frame whilst moving it.

SAFETY AND CARE

It's important to ensure children and animals are kept away from the assembly area, as there are small components used in this product which could present a choking hazard. All plastic and wrapping materials should also be kept away from children and animals to prevent any risk of suffocation.

HELP AND SUPPORT

Please contact our customer service team on 0113 519 0311 if you have any questions or issues with your purchase.


RECYCLING

Please ensure that packaging is disposed of in a safe and environmentally friendly way, and recycle where possible. Please keep your assembly instructions safe to refer back to in the future.

CARE AND MAINTENANCE:

1. Only clean using a damp cloth, do not use bleach or abrasive cleaners as they may damage the finish over time.
2. Do not use a very wet cloth or allow any liquid to contact with the veneer for a long period of time. Wipe any spillage immediately. Absorption can cause wood to warp or finishes to de-laminate.
3. Do not scrub or rub the surface when cleaning.
4. Do not drag Hattie Large Tv Unit when moving, lift it off the floor instead.
5. Use a placemat or a coaster when putting hot items (e.g. hot drinks and dishes) on the wood surface.
6. It is not recommended to place the item next to sources of heat such as radiators, fires or directly exposed to sunlight. This may cause the wood to crack, split or fade due to the heat and humidity.
7. Wood will mellow and change colour over time, we recommend that ornaments and items placed on the surface to be moved regularly to prevent uneven mellowing.
8. Regularly check all fixings to ensure none have come loose. Re-tighten if necessary.
9. Avoid sharp items such as a screwdriver or any pointy tools.
10. Dispose of all packaging carefully and responsibly - recycle where possible.

Parts list



Parts list



Before you begin building your Hattie Large Tv Unit , please take a moment to read through the instructions and make sure that you have all the relevant parts listed on the parts check list.

Part Number	Part Description	Quantity	Box No
①	Leg	4pcs	Box 1
②	Support Leg	2pcs	Box 1
③	Top Panel	1pc	Box 1
④	Bottom Panel	1pc	Box 1
⑤	Back panel	1pc	Box 1
⑥	Drawer Front	1pc	Box 1
⑦	Drawer Bottom	1pc	Box 1
⑧	Drawer Back	1pc	Box 1
⑨	Drawer Right with Slide pre-assembled	1pc	Box 1

Part Number	Part Description	Quantity	Box No
⑩	Drawer Left with Slide pre-assembled	1pc	Box 1
⑪	Door Panel	2pcs	Box 1
⑫	Left Middle Panel with Slide pre-assembled	1pc	Box 1
⑬	Right Middle Panel with Slide pre-assembled	1pc	Box 1
⑭	Side Shelf	2pcs	Box 1
⑮	Middle Shelf	1pc	Box 1
⑯	Left side panel	1pc	Box 1
⑰	Right side panel	1pc	Box 1
⑱	Drawer Support	1pc	Box 1

Fittings







Please check you have all the fittings listed below with your product in box 1.

<p>A</p>  <p>M6.3*35mm Bolt 26pcs+3pcs extra</p>	<p>B</p>  <p>Ø15*9mm Cam Lock 20pcs+2pcs extra</p>	<p>C</p>  <p>Ø8*30mm Dowel 28pcs+3pcs extra</p>	<p>D</p>  <p>Ø12*9mm Cam Lock 6pcs</p>	<p>E</p>  <p>M4*35mm Screw 6pcs</p>
<p>F</p>  <p>M3*12mm Screw 6pcs</p>	<p>G</p>  <p>M3.5*14mm Screw 24pcs+3pcs extra</p>	<p>H</p>  <p>M3.5*14mm Screw 4pcs</p>	<p>I</p>  <p>M7*38mm Screw 8pcs+1pc extra</p>	<p>J</p>  <p>M6*15mm Screw 24pcs+3pcs extra</p>
<p>K</p>  <p>Cover 12pcs+1pc</p>	<p>L</p>  <p>Handle 3pcs</p>	<p>M</p>  <p>Hinge 4pcs</p>	<p>N</p>  <p>Adjustable Feet 2pcs</p>	<p>O</p>  <p>4mm Allen Key 1pc</p>
<p>P Pre-assembled Slide</p>  <p>Slide 2pcs</p>	<p>Q Pre-assembled Screw</p>  <p>M3.5*12mm Screw 8pcs</p>			


Pre-assembled Fittig

<p>P-1</p>  <p>Slide 2pcs</p>	<p>P-2</p>  <p>Slide 2pcs</p>	<p>Q</p>  <p>M3.5*12mm Screw 8pcs</p>
---	---	---

1. Attach parts to the boards.




2. Attach parts to the boards.




<p>B</p> 	<p>C</p> 
<p>Ø15*9mm Cam Lock 4pcs</p>	<p>Ø8*30mm Dowel 4pcs</p>

3. Attach parts to the boards.




<p>B</p> 	<p>C</p> 
<p>Ø15*9mm Cam Lock 4pcs</p>	<p>Ø8*30mm Dowel 4pcs</p>

4. Attach parts to the boards.




<p>B</p> 	<p>C</p> 
<p>Ø15*9mm Cam Lock 2pcs</p>	<p>Ø8*30mm Dowel 2pcs</p>

5. Attach parts to the boards.




<p>B</p> 	<p>C</p> 
<p>Ø15*9mm Cam Lock 2pcs</p>	<p>Ø8*30mm Dowel 2pcs</p>

6. Attach parts to the boards.





B	C	K
		
Ø15*9mm Cam Lock	Ø8*30mm Dowel	Cover
8pcs	8pcs	8pcs

7. Attach back to the frame.




8. Attach parts to the boards.




C	I	H	O
			
Ø8*30mm Dowel 8pcs	M7*38mm Screw 8pcs	M3.5*14mm Screw 4pcs	4mm Allen Key 1pc

9. Assemble the leg to the frame.




J	O	N
		
M6*15mm Screw 24pcs	4mm Allen Key 1pc	Adjustable Feet 2pcs

10. Assemble the drawer.




A	D
	
M6.3*35mm Bolt 6pcs	Ø12*9mm Cam Lock 6pcs

11. Attach parts to the boards.





E	F	K	L
			
M4*35mm Screw 6pcs	M3*12mm Screw 2pcs	Cover 4pcs	Handle 1pc

12. Attach parts to the boards.



F	G	L	M
			
M3*12mm Screw 4pcs	M3.5*14mm Screw 8pcs	Handle 2pcs	Hinge 4pcs


13. Assemble doors to the frame.



G

M3.5*14mm Screw 16pcs

14. Assemble drawer to the TV Unit.



15.

