

DUSK.COM



LIVING | BEDROOM | DINING

Range Name :Posy


Box1 Dimensions : W68xD57xH12.5cm

Product Dimension : W48xD40xH59cm

Posy Nightstand



Up to 30 minutes
assembly time



Two person
assembly



Electric screwdriver
prohibited

This product is intended for domestic use only, not for commercial purposes.

P-1-12
V-1.0

IMPORTANT

ASSEMBLY TIP

Before you begin, it's best to identify all of the parts and fittings to build your Posy Nightstand frame. We advise laying these out on the floor to check you have everything, and to familiarise yourself with all of the parts and fittings before building.

TOP TIP

We recommend that you assemble the Posy Nightstand in the room you'd like it to be located.

This will help prevent any risk of damage to the frame whilst moving it.

SAFETY AND CARE

It's important to ensure children and animals are kept away from the assembly area, as there are small components used in this product which could present a choking hazard. All plastic and wrapping materials should also be kept away from children and animals to prevent any risk of suffocation.

HELP AND SUPPORT

Please contact our customer service team on 0113 519 0311 if you have any questions or issues with your purchase.


RECYCLING

Please ensure that packaging is disposed of in a safe and environmentally friendly way, and recycle where possible. Please keep your assembly instructions safe to refer back to in the future.

CARE AND MAINTENANCE:

1. Only clean using a damp cloth, do not use bleach or abrasive cleaners as they may damage the finish over time.
2. Do not use a very wet cloth or allow any liquid to contact with the veneer for a long period of time. Wipe any spillage immediately. Absorption can cause wood to warp or finishes to de-laminate.
3. Do not scrub or rub the surface when cleaning.
4. Do not drag the Posy Nightstand when moving, lift it off the floor instead.
5. Use a placemat or a coaster when putting hot items (e.g. hot drinks and dishes) on the wood surface.
6. It is not recommended to place the item next to sources of heat such as radiators, fires or directly exposed to sunlight. This may cause the wood to crack, split or fade due to the heat and humidity.
7. Wood will mellow and change colour over time, we recommend that ornaments and items placed on the surface to be moved regularly to prevent uneven mellowing.
8. Regularly check all fixings to ensure none have come loose. Re-tighten if necessary.
9. Avoid sharp items such as a screwdriver or any pointy tools.
10. Dispose of all packaging carefully and responsibly - recycle where possible.

Parts list



Parts list

















Before you begin building your Posy Nightstand , please take a moment to read through the instructions and make sure that you have all the relevant parts listed on the parts check list.

Part Number	Part Description	Quantity	Box No
①	Top Panel	1pc	Box 1
②	Bottom Panel	1pc	Box 1
③	Left side Pane with Slide pre-assembled	1pc	Box 1
④	Right side Panel with Slide pre-assembled	1pc	Box 1
⑤	Back Panel	1pc	Box 1
⑥	Drawer Front	1pc	Box 1




Part Number	Part Description	Quantity	Box No
⑦	Drawer Bottom	1pc	Box 1
⑧	Drawer Back	1pc	Box 1
⑨	Leg	4pcs	Box 1
⑩	Drawer Left with Slide pre-assembled	1pc	Box 1
⑪	Drawer Right with Slide pre-assembled	1pc	Box 1
⑫	Shelf Panel	1pc	Box 1

Fittings



Please check you have all the fittings listed below with your product in box 1.



A  M6.3*35mm Bolt 12pcs+1pc extra	B  Ø15*9mm Cam Lock 8pcs+1pc extra	C  Ø12*9mm Cam Lock 4pcs	D  Ø8*30mm Dowel 8pcs+1pc extra	E  M4*35mm Screw 4pcs
F  M6x12 mm Screw 4pcs	G  Cover 4pcs	H  M6*30mm Screw 8pcs +1pc extra	I  Handle 1pc	J  M4*18mm Screw 1pc
K  4mm Allen Key 1pc	L Pre-assembled Slide  Slide 2pcs	M Pre-assembled Screw  M3.5*12mm Screw 8pcs	O  Corner Brace 4pcs	P  M3.5*14mm Screw 4pcs
Q  Washer 8pcs+1pc extra				

Pre-assembled Fittings



L-1  Slide 2pcs	L-2  Slide 2pcs	M  M3.5*12mm Screw 8pcs
--	--	--




1. Assemble all panels on EPS foam or carpet to prevent surface scratches.





A	D
	
M6.3*35mm Bolt 4pcs	Ø8x30mm Dowel 4pcs

2. Ensure the side panel and leg tubes are level before tightening the screws, or place the assembly upside down on a flat surface before tightening.




H	K	Q
		
M6*30mm Screw 8pcs	4mm Allen Key 1pc	Washer 8pcs


3.




4.






5.




A	
	M6.3*35mm Bolt 4pcs


6.




B 	D 
Ø15*9mm Cam Lock 4pcs	Ø8x30mm Dowel 4pcs



7.




F	
	M6x12 mm Screw 4pcs

8.




A 	C 
M6.3*35mm Bolt 4pcs	Ø12*9mm Lock 4pcs

9.






E	
M4*35mm Screw	
4pcs	

10.





G		I	J
Cover		Handle	M4*18mm
4pcs		1pc	1pc


11.





12.



13.



<div>O</div> 	<div>P</div> 
Corner Brace	M3.5*14mm Screw
4pcs	4pcs

14.

