
DUSK.COM LIVING I BEDROOM I DINING

Range Name :Romilly

Box1 dimensions :W89xD46.5xH22cm Product Dimension :W79xD40xH65cm

Romilly 3 Drawer Chest





Up to 60 minutes assembly time



Two person assembly



Electric screwdriver prohibited

This product is intended for domestic use only,not for commercial purposes.

IMPORTANT

ASSEMBLY TIP

Before you begin, it's best to identify all of the parts and fittings to build your Romilly 3 Drawer Chest Cabinet frame. We advise laying these out on the floor to check you have everything, and to familiarise yourself with all of the parts and fittings before building.

TOP TIP

We recommend that you assemble the Romilly 3 Drawer Chest Cabinet in the room you'd like it to be located

This will help prevent any risk of damage to the frame whilst moving it.

SAFETY AND CARE

It's important to ensure children and animals are kept away from the assembly area, as there are small components used in this product which could present a choking hazard. All plastic and wrapping materials should also be kept away from children and animals to prevent any risk of suffocation.

HELP AND SUPPORT

Please contact our customer service team on 0113 519 0311 if you have any questions or issues with your purchase.

RECYCLING

Please ensure that packaging is disposed of in a safe and environmentally friendly way, and recycle where possible. Please keep your assembly instructions safe to refer back to in the future.

CARE AND MAINTENANCE:

- 1. Only clean using a damp cloth, do not use bleach or abrasive cleaners as they may damage the finish over time.
- 2. Do not use a very wet cloth or allow any liquid to contact with the veneer for a long period of time. Wipe any spillage immediately. Absorption can cause wood to warp or finishes to de-laminate.
- 3.Do not scrub or rub the surface when cleaning.
- 4. Do not drag the Romilly 3 Drawer Chest Cabinet when moving, lift it off the floor instead.
- 5. Use a placemat or a coaster when putting hot items (e.g. hot drinks and dishes) on the wood surface.
- 6. It is not recommended to place the item next to sources of heat such as radiators, fires or directly exposed to sunlight. This may cause the wood to crack, split or fade due to the heat and humidity.
- 7. Wood will mellow and change colour over time, we recommend that ornaments and items placed on the surface to be moved regularly to prevent uneven mellowing.
- 8. Regularly check all fixings to ensure none have come loose. Re-tighten if necessary.
- 9. Avoid sharp items such as a screwdriver or any pointy tools.
- 10. Dispose of all packaging carefully and responsibly recycle where possible.

Parts list **(5)**

Parts list


Before you begin building your Romilly 3 Drawer Chest Cabinet, please take a moment to read through the instructions and make surethat you have all the relevant parts listed on the parts check list.

Part Number	Part Description	Quantity	Box No
1	Top Panel	1pc	Box 1
2	Bottom Panel	1pc	Box 1
3	Left Side Panel with Slide pre-assembled	1pc	Box 1
4	Right Side Panel with Slide pre-assembled	1pc	Box 1
5	Drawer Front	3pcs	Box 1
6	Drawer Left with Slide pre-assembled	3pcs	Box 1
7	Drawer Right with Slide pre-assembled	3pcs	Box 1
8	Drawer Back	3pcs	Box 1
9	Drawer Bottom	3pcs	Box 1
10	Drawer Bottom Support	3pcs	Box 1

Part Number	Part Description	Quantity	Box No
11	Centre Support	1pc	Box 1
12	Connect Bar	2pcs	Box 1
13	Left Kick Plate	1рс	Box 1
14	Right Kick Plate	1рс	Box 1
15	Front Kick Plate	1рс	Box 1
16	Rear Kick Plate	1pc	Box 1
17	Back Panell	2pcs	Box 1
18	Plastic Slot	1рс	Box 1
19	Back Support Bar	1рс	Box 1


Fittings


Please check you have all the fittings listed below with your product in box 1.




Pre-assembled Fittings


Foot pad 4pcs








2. 12 12 E x 6 G1 x 3 Е G TIME) Damper M3.5*14mm Screw P-7-23 V-1.0 6pcs 3pcs




















































After assembling G1 and G2 into G, rotate the front cylindrical part of G counterclockwise by 3mm.






















P-17-23 V-1.0


























P-21-23 V-1.0




- To open drawer:
 Press firmly on the circle-drawing area until the drawer releases.
 Do not press on edges.









Adjust the damper to achieve optimal cushioning range for smooth closing.