

DUSK.COM

LIVING | BEDROOM | DINING

Range Name: New Ruby


Box1 Dimensions: W197.5xD63xH12.5 (cm)

Box2 Dimensions: W104xD60xH20.5 (cm)

Box3 Dimensions: W195xD62xH16 (cm)

Product Dimensions: W182xD55xH180 (cm)


4 Door Wardrobe



THIS INSTRUCTION BOOKLET CONTAINS IMPORTANT SAFETY INFORMATION.
PLEASE READ AND KEEP FOR FUTURE REFERENCE.



Up to 120 minutes
assembly time



Three person
assembly



Electric screwdriver
prohibited

This product is intended for domestic use only, not for commercial purposes.

V-1.0
P-1/20

IMPORTANT

ASSEMBLY TIP

Before you begin, it's best to identify all of the parts and fittings to build your 4 Door Wardrobe frame. We advise laying these out on the floor to check you have everything, and to familiarise yourself with all of the parts and fittings before building.

TOP TIP

We recommend that you assemble the bedside in the room you'd like it to be located. This will help prevent any risk of damage to the frame whilst moving it.

SAFETY AND CARE

1. It's important to ensure children and animals are kept away from the assembly area, as there are small components used in this product which could present a choking hazard. All plastic and wrapping materials should also be kept away from children and animals to prevent any risk of suffocation.
2. Do not stand on your product.
3. Always use the item on firm level ground, ensuring all legs remain in contact with the ground.
4. Place heaviest items in the lowest drawers.
5. Do not set TV or other heavy objects on top of the product.
6. Children should always be under supervision whilst using this product. Never allow children to climb on the drawers.
7. Never keep more than one drawer open at the same time.
8. In order to prevent overturning, this product must be used with the wall attachment device provided.
9. Serious or fatal crushing injuries can occur from tipping furniture.

HELP AND SUPPORT

Please contact our customer service team on 0113 519 0311 if you have any questions or issues with your purchase.


RECYCLING

Please ensure that packaging is disposed of in a safe and environmentally friendly way, and recycle where possible. Please keep your assembly instructions safe to refer back to in the future.

CARE AND MAINTENANCE

1. Only clean using a damp cloth, do not use bleach or abrasive cleaners as they may damage the finish over time.
2. Do not use a very wet cloth or allow any liquid to contact with the surface for a long period of time. Wipe any spillage immediately. Absorption can cause wood to warp or finishes to de-laminate.
3. Do not scrub or rub the surface when cleaning.
4. Do not drag the 4 Door Wardrobe when moving, lift it off the floor instead.
5. Use a placemat or a coaster when putting hot items (e.g. hot drinks and dishes) on the wood surface.
6. It is not recommended to place the item next to sources of heat such as radiators, fires or directly exposed to sunlight. This may cause the wood to crack, split or fade due to the heat and humidity.
7. Wood will mellow and change colour over time, we recommend that ornaments and items placed on the surface to be moved regularly to prevent uneven mellowing.
8. Regularly check all fixings to ensure none have come loose. Re-tighten if necessary.
9. Avoid sharp items such as a screwdriver or any pointy tools.

Parts list








Parts list

Before you begin building your 4 Door Wardrobe, please take a moment to read through the instructions and make sure that you have all the relevant parts listed on the parts check list.

Part Number	Part Description	Quantity	Box No
1	Top Panel	1 pc	Box1
2	Bottom Panel	1 pc	Box1
3	Left Side Panel	1 pc	Box3
4	Right Side Panel With Slide Pre-assembled	1 pc	Box3
5	Middle Panel With Slide Pre-assembled	1 pc	Box3
6	Left Shelf Side Panel	1 pc	Box2
7	Right Shelf Side Panel	1 pc	Box2
8	Top Support Bar	1 pc	Box1
9	Back Support Bar	1 pc	Box2
10	Hanging Bar	2 pcs	Box2
11	Bottom Support Bar	1 pc	Box2
12	Back Support Bar	2 pcs	Box2
13	Back Support Bar	4 pcs	Box2
14	Back Panel	5 pcs	Box2
15	Back Panel	1 pc	Box2
16	Leg Long Panel	2 pcs	Box1
17	Drawer Front	2 pcs	Box2
18	Leg Short Panel	3 pcs	Box2
19	Left Door Panel	1 pc	Box1
20	Middle Door Panel	1 pc	Box1
21	Middle Door Panel	1 pc	Box3
22	Right Door Panel	1 pc	Box3
23	Drawer Left Side With Slide Pre-assembled	2 pcs	Box2
24	Drawer Right Side With Slide Pre-assembled	2 pcs	Box2
25	Drawer Back Side	2 pcs	Box2
26	Drawer Bottom	2 pcs	Box2
27	Drawer Bottom Support Bar	4 pcs	Box2

Fittings


Please check you have all the fittings listed below with your product in Box2.

						
<p>M5*35mm Cam Lock Screw</p> <p>113pcs+4pcs extra</p>	<p>Ø15*10mm Cam Lock</p> <p>113pcs+4pcs extra</p>	<p>Ø8*30mm Dowel</p> <p>33pcs+4pcs extra</p>	<p>M4*35mm Screw</p> <p>16pcs+2pcs extra</p>	<p>Cover</p> <p>22pcs+2pcs extra</p>	<p>Plastic Buckle</p> <p>36pcs+4pcs extra</p>	<p>M3*12mm Screw</p> <p>44Tpcs+4pcs extra</p>
						
<p>Handle</p> <p>8pcs</p>	<p>M4*20mm Bolt</p> <p>4pcs</p>	<p>Wooden Block</p> <p>2pcs</p>	<p>M4*40mm Screw</p> <p>10pcs+1pc extra</p>	<p>M4*14mm Screw</p> <p>106pcs+4pcs extra</p>	<p>Wall Bracket</p> <p>4pcs</p>	<p>M4*12mm Screw</p> <p>12pcs+1pc extra</p>
						
<p>M8*40mm Wall Anchor</p> <p>4pcs</p>	<p>Tube Bracket</p> <p>4pcs</p>	<p>Door Catch</p> <p>4pc</p>	<p>M3*16mm Screw</p> <p>8pcs+1pc extra</p>	<p>M4*30mm Screw</p> <p>7pcs</p>	<p>Hinge</p> <p>8pcs</p>	<p>Hinge</p> <p>8pcs</p>
						
<p>Mat</p> <p>10pcs+1pc extra</p>	<p>M4*10mm Bolt</p> <p>4pcs</p>					


Pre- assembled Fitting

		
<p>Slide</p> <p>4pcs</p>	<p>Slide</p> <p>4pcs</p>	<p>M3.5*12mm Screw</p> <p>24pcs</p>


Ensure the cam lock screws are installed correctly, as indicated by the "check mark" below.




Refer to the illustration below to correctly use the cam lock screws for assembling the panels.




1. Attach parts to the side panel.



2. Attach parts to the middle panel.




3. Assemble the panels of each part together according to the diagram.




4. Assemble back panel.


Pay attention to adjust the direction of the back panel so that the hole positions align with the No. 7 shelf panel.




5. Assemble the panels of each part together according to the diagram.



6. Assemble the panels of each part together according to the diagram.




7. Assemble the panels of each part together according to the diagram.




<p>B</p> 	<p>C</p> 
<p>Ø15*10mm Cam Lockk 11pcs</p>	<p>Ø8*30mm Dowel 4pcs</p>

8. Attach parts to the panel.




<p>A</p> 
<p>M5*35mm Cam Lock Screw 29pcs</p>

9. Assemble the leg panels of each part together according to the diagram.




B	
Ø15*10mm Cam Lockk	
12pcs	

10. Assemble the panels of each part together according to the diagram.



B		C	
Ø15*10mm Cam Lockk		Ø8*30mm Dowel	
14pcs		4pcs	


11. Assemble the panels of each part together according to the diagram.




B	
Ø15*10mm Cam Lockk	
10pcs	

C	
Ø8*30mm Dowel	
2pcs	

12. Assemble the panels of each part together according to the diagram.




S	
M4*30mm Screw	
4pcs	

Q	
Door Catch	
2pc	

R	
M3*16mm Screw	
4pcs	


J	
Wooden Block	
2pcs	

13. Assemble the panels of each part together according to the diagram.



B	
Ø15*10mm Cam Lockk	
1pc	


14. Assemble the panels of each part together according to the diagram.




B		C	
Ø15*10mm Cam Lockk		Ø8*30mm Dowel	
19pcs		4pcs	


15. Attach parts to the panel.

E		V	
	Cover		Mat
	5pcs		10pcs




16. Attach parts to the top panel.

A	
	M5*35mm Cam Lock Screw
	15pcs





17. Attach the top panel to the frame.




K 	E 
M4*40mm Screw 6pcs	Cover 9pcs
B 	C 
Ø15*10mm Cam Lock 15pcs	Ø8*30mm Dowel 13pcs

18. Attach parts to the panel.




P 	R 
Tube Bracket 4pcs	M3*16mm Screw 4pcs
Q 	
Door Catch 2pc	

19. Assemble the drawer by following the steps shown in the illustration below.




D	
M4*35mm Screw	
16pcs	

20. Attach parts to the drawer panel.



A		H		W	
M5*35mm Cam Lock Screw		Handle		M4*10mm Bolt	
12pcs		4pcs		4pcs	



21. Assemble the drawer by following the steps shown in the illustration below.




x2

<p>B</p>  <p>Ø15*10mm Cam Lockk 12pcs</p>	<p>E</p>  <p>Cover 8pcs</p>
---	---

22. Assemble drawer in the cabinet.




23. Attach parts to the door panel.






H		I		Q		G		T		L		U	
Handle		M4*20mm Bolt		Door Catch		M3*12mm Screw		Hinge		M4*14mm Screw		Hinge	
2pcs		2pcs		2pcs		4pcs		4pcs		16pcs		4pcs	

24. Attach parts to the door panel.




H		I		Q		G		T		L		U	
Handle		M4*20mm Bolt		Door Catch		M3*12mm Screw		Hinge		M4*14mm Screw		Hinge	
2pcs		2pcs		2pcs		4pcs		4pcs		16pcs		4pcs	


25. Assemble the door panel onto the cabinet and adjust it as shown in the picture, Make the door gap even and smooth.



25. Attach the plastic buckles and screws etc.




NB: Before tightening the plastic buckles and screws, please ensure the frame is square



F	G	M	N
			
Plastic Buckle	M3*12mm Screw	Wall Bracket	M4*12mm Screw
36pcs	36pcs	4pcs	12pcs

26. Drill holes in the wall, insert expansion bolts, and then fix the furniture to the wall with screws.



Avoid handles touch, please don't open the two doors at the same time

O	K
M8*40mm Wall Anchor 4pcs	M4*40mm Screw 4pcs