

# DUSK.COM



LIVING | BEDROOM | DINING

Range Name : Lucy


Box1 Dimension : W110xD108xH14.5cm

Product Dimension : W100xD100xH76cm

## Lucy Dining Table 4 Seater



Up to 30 minutes  
assembly time



Two person  
assembly



Electric screwdriver  
prohibited

This product is intended for domestic use only, not for commercial purposes.

P-1-9  
v-1.0

## IMPORTANT

### ASSEMBLY TIP

Before you begin, it's best to identify all of the parts and fittings to build your Lucy Dining Table 4 Seater. We advise laying these out on the floor to check you have everything, and to familiarise yourself with all of the parts and fittings before building.

### TOP TIP

We recommend that you assemble the Lucy Dining Table 4 Seater in the room you'd like it to be located. This will help prevent any risk of damage to the frame whilst moving it.

### SAFETY AND CARE

It's important to ensure children and animals are kept away from the assembly area, as there are small components used in this product which could present a choking hazard. All plastic and wrapping materials should also be kept away from children and animals to prevent any risk of suffocation.

### HELP AND SUPPORT

Please contact our customer service team on 0113 519 0311 if you have any questions or issues with your purchase.


### RECYCLING

Please ensure that packaging is disposed of in a safe and environmentally friendly way, and recycle where possible. Please keep your assembly instructions safe to refer back to in the future.

### CARE AND MAINTENANCE:

1. Only clean using a damp cloth, do not use bleach or abrasive cleaners as they may damage the finish over time.
2. Do not use a very wet cloth or allow any liquid to contact with the veneer for a long period of time. Wipe any spillage immediately. Absorption can cause wood to warp or finishes to de-laminate.
3. Do not scrub or rub the surface when cleaning.
4. Do not drag the Lucy Dining Table 4 Seater when moving, lift it off the floor instead.
5. Use a placemat or a coaster when putting hot items (e.g. hot drinks and dishes) on the wood surface.
6. It is not recommended to place the item next to sources of heat such as radiators, fires or directly exposed to sunlight. This may cause the wood to crack, split or fade due to the heat and humidity.
7. Wood will mellow and change colour over time, we recommend that ornaments and items placed on the surface to be moved regularly to prevent uneven mellowing.
8. Regularly check all fixings to ensure none have come loose. Re-tighten if necessary.
9. Avoid sharp items such as a screwdriver or any pointy tools.
10. Dispose of all packaging carefully and responsibly - recycle where possible.

# Parts list











# Parts list

Before you begin building your Lucy Dining Table 4 Seater ,please take a moment to read through the instructions andmake surethat you have all the relevant parts listed on the parts check list.

Part Number	Part Description	Quantity	Box No
①	Top Panel	1pc	Box 1
②	Support Panel	1pc	Box 1
③	Leg Panel	4pcs	Box 1


# Fittings

Please check you have all the fittings listed below with your product in box 1.


<div>A</div> <div></div> <div>M6*28mm Screw 4pcs</div>	<div>B</div> <div></div> <div>M6*50mm Screw 8pcs+1pc extra</div>	<div>C</div> <div></div> <div>M7*35mm Screw 8pcs+1pc extra</div>	<div>D</div> <div></div> <div>Ø8*30mm Dowel 12pcs+1pc extra</div>	<div>E</div> <div></div> <div>Ø9*11 Nut 8pcs+1pc extra</div>
<div>F</div> <div></div> <div>Ø22*6*M6*15 Adjustable 4pcs</div>	<div>G</div> <div></div> <div>4mm Allen Key 2pcs</div>	<div>H</div> <div></div> <div>Cover 16pcs+2pc extra</div>		



1.




D



Ø8\*30mm Dowel  
8pcs


F




Ø22\*6\*M6\*15 Adjustable  
4pc

x4PCS

2.




B




M6\*50mm Screw  
4pcs

E



Ø9\*11 Nut  
4pcs



G






4mm Allen Key  
2pcs



x2PCS

3.





B		E		G	
M6*50mm Screw 4pcs		Ø9*11 Nut 4pcs		4mm Allen Key 2pcs	

4.






5.



D	
Ø8*30mm Dowel	
4pcs	



6.





C		G	
M7*35mm Screw		4mm Allen Key	
8pcs		1pc	



7.



A	H
	
M6*28mm Screw 4pcs	Cover 16pcs

8.

