

DUSK.COM



LIVING | BEDROOM | DINING

Range Name : NELL


Box1 dimensions : W106xD37.5xH25cm

Product dimensions : W58xD28.5xH178cm

Nell Tall Bookshelf



Up to 30 minutes
assembly time



Two person
assembly

This product is intended for domestic use only, not for commercial purposes.

P-1-14
V-2.0

IMPORTANT

ASSEMBLY TIP

Before you begin, it's best to identify all of the parts and fittings to build your Tall Bookshelf frame. We advise laying these out on the floor to check you have everything, and to familiarise yourself with all of the parts and fittings before building.

TOP TIP

We recommend that you assemble the Tall Bookshelf in the room you'd like it to be located. This will help prevent any risk of damage to the frame whilst moving it.

SAFETY AND CARE

It's important to ensure children and animals are kept away from the assembly area, as there are small components used in this product which could present a choking hazard. All plastic and wrapping materials should also be kept away from children and animals to prevent any risk of suffocation.

HELP AND SUPPORT

Please contact our customer service team on 0113 519 0311 if you have any questions or issues with your purchase.


RECYCLING

Please ensure that packaging is disposed of in a safe and environmentally friendly way, and recycle where possible. Please keep your assembly instructions safe to refer back to in the future.

CARE AND MAINTENANCE:

1. Only clean using a damp cloth, do not use bleach or abrasive cleaners as they may damage the finish over time.
2. Do not use a very wet cloth or allow any liquid to contact with the veneer for a long period of time. Wipe any spillage immediately. Absorption can cause wood to warp or finishes to de-laminate.
3. Do not scrub or rub the surface when cleaning.
4. Do not drag the Tall Bookshelf when moving, lift it off the floor instead.
5. Use a placemat or a coaster when putting hot items (e.g. hot drinks and dishes) on the wood surface.
6. It is not recommended to place the item next to sources of heat such as radiators, fires or directly exposed to sunlight. This may cause the wood to crack, split or fade due to the heat and humidity.
7. Wood will mellow and change colour over time, we recommend that ornaments and items placed on the surface to be moved regularly to prevent uneven mellowing.
8. Regularly check all fixings to ensure none have come loose. Re-tighten if necessary.
9. Avoid sharp items such as a screwdriver or any pointy tools.
10. Dispose of all packaging carefully and responsibly - recycle where possible.

Parts list











Parts list

Before you begin building your Nell Tall Bookshelf, please take a moment to read through the instructions and make sure that you have all the relevant parts listed on the parts check list.


Part Number	Part Description	Quantity	Box No	Part Number	Part Description	Quantity	Box No
①	Top	1pc	Box 1	⑪	Right Down Side Strip	1pc	Box 1
②	Left Up Side Panel	1pc	Box 1	⑫	Top Support Strip	1pc	Box 1
③	Right Up Side Panel	1pc	Box 1	⑬	Bottom Support Strip	1pc	Box 1
④	Left Down Side Panel	1pc	Box 1	⑭	Top Back Panel	1pc	Box 1
⑤	Right Down Side Panel	1pc	Box 1	⑮	Back Panel	5pcs	Box 1
⑥	Fixed Panel	4pcs	Box 1	⑯	Back Support Strip	2pcs	Box 1
⑦	Panel	1pc	Box 1	⑰	Right Up Side Strip	1pc	Box 1
⑧	Bottom Panel	1pc	Box 1				
⑨	Left Up Side Strip	1pc	Box 1				
⑩	Left Down Side Strip	1pc	Box 1				

Fittings









Please check you have all the fittings listed below with your product in box 1.

A  Ø6x30mm Dowel 64pcs+8pcs extra	B  M6*35mm Bolt 50pcs+6pcs extra	C  Ø15x9.5mm Cam Lock 50pcs+6pcs extra	D  M4*40mm Screw 6pcs
E  Anti-fall rope Gasket M4*14mm Screw 1set	F  Plastic buckle M3*16mm Screw 14sets+1set extra	N  Foot Gasket 4pcs	L  Hole Gasket 50pcs+6pcs extra



1.Attach parts to the panels.




2.Attach strips to the panels.







3. Attach panels to the side panel.




4. Attach back panel to the panel.





5. Attach left down side panel to the frame.




6. Attach back panel to the frame.





7. Attach panels to the side panel.




8. Assemble back panel.





9. Attach left up side panel to the frame.





10. Assemble back panel.







11. Attach the top to the frame.




12. Attach the middle panel to the frame.





13. Attach the upper and lower frames.



14.Assemble the plastic buckles and anti-fall rope.



E

Anti-fall rope Gasket M4*14mm Screw
1set

F

Plastic buckle M3*16mm Screw
14sets

WARNING: Please make the choice of screws according to your own wall for wall locking. In order to prevent overturning this product must be used with the wall attachment device provided.

