

Range Name: Poppy/Nell

Product Dimensions: Poppy:L77 x W24 x H108 (cm)

Nell:L80 x W25.5 x H108 (cm)

Shoe Cabinet



THIS INSTRUCTION BOOKLET CONTAINS IMPORTANT SAFETY INFORMATION.
PLEASE READ AND KEEP FOR FUTURE REFERENCE.





50 minutes approx assembly time

Two adults assembly required

This product is intended for domestic use only, not for commercial purposes.

Important

Assembly Tip

Before you begin, we advise laying everything out on a clean and soft level surface to avoid damaging the unit or your floor. It's best to identify all of the parts and fittings to build your shoe cabinet, and to familiarise yourself with all of the parts and fittings before building.

Top Tip

We recommend that you build your new shoe cabinet in the room you'd like it to be located. This will help prevent any risk of damage to the product whilst moving it.

Safety and Care

- It's important to ensure children and animals are kept away from the assembly area, as
 there are small components used in this shoe cabinet which could present a choking hazard.
 All plastic and wrapping materials should also be kept away from children and animals
 to prevent any risk of suffocation.
- 2. Do not stand on your product.
- 3. Always use the item on firm level ground, ensuring all legs remain in contact with the ground.
- 4. Place heaviest items in the lowest drawers.
- 5. Do not set TV or other heavy objects on top of the product.
- 6. Children should always be under supervision whilst using this product. Never allow children to climb on the drawers.
- 7. Never keep more than one drawer open at the same time.
- 8. The installation of anti tipping kit to secure your furniture is strongly suggested.
- 9. Serious or fatal crushing injuries can occur from tipping furniture.

Help and Support

Please contact our customer service team on 0113 519 0311 if you have any questions or issues with your purchase.

Recycling

Please ensure that packaging is disposed of in a safe and environmentally friendly way, and recycle where possible. Please keep your assembly instructions safe to refer back to in the future.

Care and Maintenance

- 1. Only clean using a damp cloth, do not use bleach or abrasive cleaners as they may damage the finish over time.
- 3. Do not scrub or rub the surface when cleaning.
- 2. Do not use a very wet cloth or allow any liquid to contact with the veneer for a long period of time. Wipe any spillage immediately. Absorption can cause wood to warp or finishes to de-laminate.
- 4. Do not drag the shoe cabinet when moving, lift it off the floor instead.
- 5. Use a placemat or a coaster when putting hot items (e.g. hot drinks and dishes) on the wood surface.
- 6. It is not recommended to place the item next to sources of heat such as radiators, fires or directly exposed to sunlight. This may cause the wood to crack, split or fade due to the change of the humidity and temperature.
- 7. Wood will mellow and change colour over time, we recommend that ornaments and items placed on the surface to be moved regularly to prevent uneven mellowing.
- 8. Regularly check all fixings to ensure none have come loose. Re-tighten if necessary.
- 9. Avoid sharp items such as a screwdriver or any pointy tools.

Parts checklist

Please check you have all the parts listed below with your product:


Do not discard any of the packaging until you have checked that you have all the parts and the pack of fixings.

Note: There are 2 styles of part 1,both assemble identically so please follow the same instructions for whichever style you have chosen. Part 1 is packed in other boxes.


Part Number	Part Description	Qty	
1	Top Panel	1 pc	
2	Left Panel	1 pc	
3	Right Panel	1 pc	1
4	Bottom Support Bar	1 pc	OR
5	Bottom Panel	1 pc	1
6	Bottom Back Panel	1 pc	15
7	Middle Back Panel	1 pc	10
8	Upper Back Panel	1 pc	8 19
9	Middle Panel	1 pc	9 14
10	Upper Support Bar	1 pc	
11	Flip Drawer Front	2 pcs	7 3
12	Flip Drawer Back Side	4 pcs	
13	Flip Drawer Bottom	2 pcs	
14	Top Drawer Front	1 pc	6 12 x2
15	Top Drawer Back Side	1 pc	13 x2
16	Top Drawer Left Side	1 pc	
17	Top Drawer Right Side	1 pc	5
18	Top Drawer Support Bar	1 pc	11 x2
19	Top Drawer Bottom	1 pc	

Fittings checklist


Please check you have all the fittings listed below with your product:





Bolt Length Ruler:




Tool required









Step 5: Attach Bottom Back Panel (6) to the frame.



Step 6: Attach Right Panel (3) to the frame.





Step 7: Insert Upper Back Panel (8) to the frame.




Step 8: Attach cam bolts and wall bracket to Top Panel (1).


4pcs







Step 10: Attach slide rail to Top Drawer Side panels (16, 17), then attach the top drawer.










Step 15: Attach the Flip Drawer Back Side panel (12) to the flip shelf middle, and attach the handles to Flip Drawer Front.


4pcs

4pcs

 \bigcirc



Page 12



Step 18: Attach the top drawer to the frame.