





ROBIN REACTIVE BULB TABLE LAMP



1




2




Step 1: Use a screwdriver to loosen the screw and open the battery case cover.


Step 2: Remove the old batteries and replace them with the new.




3



Step 3: Close the battery case cover and tighten the screw. Then turn the switch to "ON" position and light up.



(3 X AAA BATTERIES NOT INCLUDED)



Q.C APPROVED
10/10/2024
ISSUE 1



• **Safety Information: (Please retain for future reference)**

About this product:

- Suitable for indoor and outdoor use
- Operation Voltage: 4.5V~ 3 x AAA batteries not included
- Please remove all the packaging before use.
- Slide open the battery cover and insert the 3 x AAA batteries required into the compartment according to the diagram on the inside of the battery compartment.
- This product contain non-replaceable LED lamps, if the LED lamp reach the end of their life the whole product must be replaced.

Warnings:

- This is a decoration product and NOT a toy, keep out of the reach of babies and children.
- Battery leakage can cause corrosion and damage to this product. We not recommend the batteries are left in this product when not in use for long periods. Only batteries of the same or equivalent type are recommended to be used.
- Do not mix old and new batteries.
- Dispose of the old batteries safely, do not attempt to burn them and use collection points where available.
- Make sure the battery compartment are securely closed all the time.



This symbol indicates that the item should be disposed of separately from household waste. The item should be handed in for recycling in accordance with local environmental regulations for waste disposal. By separating a marked item from household waste you will help reduce the volume of waste sent to incinerators or land-fill and minimize any potential negative impact on human health and the environment.