

DUSK.COM



LIVING | BEDROOM | DINING

Range Name : Posy


Box1 dimensions :W69.5xD36.5xH21.5cm

Product Dimension:W60xD30xH60cm

Posy Under The Sink Cabinet



Up to 60 minutes
assembly time



Two person
assembly



Electric screwdriver
prohibited

This product is intended for domestic use only, not for commercial purposes.

P-1-15
V-1.0

IMPORTANT

ASSEMBLY TIP

Before you begin, it's best to identify all of the parts and fittings to build your Posy Under The Sink Cabinet frame. We advise laying these out on the floor to check you have everything, and to familiarise yourself with all of the parts and fittings before building.

TOP TIP

We recommend that you assemble Posy Under The Sink Cabinet in the room you'd like it to be located.

This will help prevent any risk of damage to the frame whilst moving it.

SAFETY AND CARE

It's important to ensure children and animals are kept away from the assembly area, as there are small components used in this product which could present a choking hazard. All plastic and wrapping materials should also be kept away from children and animals to prevent any risk of suffocation.

HELP AND SUPPORT

Please contact our customer service team on 0113 519 0311 if you have any questions or issues with your purchase.

RECYCLING

Please ensure that packaging is disposed of in a safe and environmentally friendly way, and recycle where possible. Please keep your assembly instructions safe to refer back to in the future.

CARE AND MAINTENANCE:

1. Do not drag Posy Under The Sink Cabinet when moving, lift it off the floor instead.
2. It is not recommended to place the item next to sources of heat such as radiators, fires or directly exposed to sunlight. This may cause the wood to crack, split or fade due to the heat and humidity.
3. Wood will mellow and change colour over time, we recommend that ornaments and items placed on the surface to be moved regularly to prevent uneven mellowing.
4. Regularly check all fixings to ensure none have come loose. Re-tighten if necessary.
5. Avoid sharp items such as a screwdriver or any pointy tools.
6. Dispose of all packaging carefully and responsibly - recycle where possible.

▲ To keep your bathroom furniture looking its best, please follow the guidance below.

Cleaning

1. Clean with a soft damp cloth and mild soap solution only.
2. Dry surfaces thoroughly after cleaning.
3. Do not use abrasive cleaners, scouring pads or bleach as these may damage the finish.


Moisture & Ventilation

1. Always wipe away standing water immediately, particularly around joints, edges, basins, and handles.
2. Ensure the room is well ventilated during and after bathing or showering to reduce humidity build-up.
3. Prolonged exposure to moisture or poor ventilation may cause swelling, edge lifting, or deterioration of the finish over time.

Heat & Steam

1. Avoid direct contact with excessive heat or steam.
2. Avoid scratches, and sharp objects which may damage the painted surface.
3. Slight colour variation or fading over time may occur due to natural exposure to light.

Parts list



Parts list


Before you begin building your Posy Under The Sink Cabinet, please take a moment to read through the instructions and make sure that you have all the relevant parts listed on the parts check list.

Part Number	Part Description	Quantity	Box No
①	Top Panel	1pc	Box 1
②	Shelf	1pc	Box 1
③	Bottom Panel	1pc	Box 1
④	Left Side Panel	1pc	Box 1
⑤	Right Side Panel	1pc	Box 1

Part Number	Part Description	Quantity	Box No
⑥	Left Back Panel	1pc	Box 1
⑦	Right Back Panel	1pc	Box 1
⑧	Door panel	2pcs	Box 1
⑨	Leg	4pcs	Box 1

Fittings

Please check you have all the fittings listed below with your product in box1.

A

M6.3*35mm Bolt
20pcs+2pcs extra

B


Ø15*9mm Cam Lock
20pcs+2pcs extra

C


Ø8*30mm Dowel
16pcs+2pcs extra

D

M6*30mm Screw
12pcs+1pc extra

E


M7*38mm Screw
6pcs

F

4mm Allen Key
1pc

G

M3.5*14mm Screw
24pcs+3pcs extra

H

Straight Arm Hinge
4pcs

I

Handle
2pcs

J

M4*18mm Screw
2pcs

K

Anti-tipping Belt
2pcs

L

Washer
16pcs+2pcs extra

M

M4*14mm Screw
2pcs

N

8mm Wall Plug
2pcs





O

M5*35mm Screw
2pcs


P

Cover
20pcs+4pcs extra

1. Assemble all panels on EPS foam or carpet to prevent surface scratches.




2.




B	C
	
Ø15*9mmCam Lock	Ø8*30mm Dowel
4pcs	4pcs


3.




B	C
	
Ø15*9mmCam Lock	Ø8*30mm Dowel
2pcs	2pcs

4.




E 	F 
M7*38mm Screw 3pcs	4mm Allen Key 1pc

5.




B 	C 
Ø15*9mm Cam Lock 4pcs	Ø8*30mm Dowel 4pcs


6.




B		C	
Ø15*9mm Cam Lock		Ø8*30mm Dowel	
2pcs		2pcs	

7.




E		F	
M7*38mm Screw		4mm Allen Key	
3pcs		1pc	

8.




B	C
	
Ø15*9mm Cam Lock 8pcs	Ø8*30mm Dowel 4pcs

9.



D	L	F
		
M6*30mm Screw 12pcs	Washer 12pcs	4mm Allen Key 1pc


10.



G	H
	
M3.5*14mm Screw 8pcs	Straight Arm Hinge 4pcs


x 2pcs

11.





G	I	J
		
M3.5*14mm Screw 16pcs	Handle 2pcs	M4*18mm Screw 2pcs

12.





K	L	M
		
Anti-tipping Belt 2pcs	Washer 2pcs	M4*14mm Screw 2pcs

13. Use Cover P to cover all the positions where use Cam Lock B to prevent moisture.



P	
	Cover
	20pcs

14.



L	N	O
		
Washer 2pcs	8mm Allen Key 2pcs	M5*35mm Screw 2pcs