

DUSK.COM

LIVING I BEDROOM I DINING


Range Name : Mila
Box1 Dimension :W116xD69xH16m
Box2 Dimension :W210.5xD69xH13cm
Product Dimension :W100xD60xH200cm

2 Door Wardrobe





Up to 90 minute
sassembly time



Two person
assembly



Electric screwdriver
prohibited

This product is intended for domestic use only,not for commercial purposes.

P-1-16
V-1.0

IMPORTANT

ASSEMBLY TIP

Before you begin, it's best to identify all of the parts and fittings to build your Mila 2 Door Wardrobe fr ame. We advise laying these out on the floor to check you have everything, and to familiarise yoursel f with all of the parts and fittings before building.

TOP TIP

We recommend that you assemble the Mila 2 Door Wardrobe in the room you'd like it to be located. This will help prevent any risk of damage to the frame whilst moving it.

SAFETY AND CARE

It's important to ensure children and animals are kept away from the assembly area, as there are small components used in this product which could present a choking hazard. All plastic and wrapping materials should also be kept away from children and animals to prevent any risk of suffocation.

HELP AND SUPPORT

Please contact our customer service team on 0113 519 0311 if you have any questions or issues with your purchase.

RECYCLING

Please ensure that packaging is disposed of in a safe and environmentally friendly way, and recycle where possible. Please keep your assembly instructions safe to refer back to in the future.

CARE AND MAINTENANCE:

1. Only clean using a damp cloth, do not use bleach or abrasive cleaners as they may damage the finish over time.

2. Do not use a very wet cloth or allow any liquid to contact with the veneer for a long period of time. Wipe any spillage immediately. Absorption can cause wood to warp or finishes to de-laminate.

3.Do not scrub or rub the surface when cleaning.

4. Do not drag the Mila 2 Door Wardrobe when moving, lift it off the floor instead.

5. Use a placemat or a coaster when putting hot items (e.g. hot drinks and dishes) on the wood surface.

6. It is not recommended to place the item next to sources of heat such as radiators, fires or directly exposed to sunlight. This may cause the wood to crack, split or fade due to the heat and humidity.


7. Wood will mellow and change colour over time, we recommend that ornaments and items placed on the surface to be moved regularly to prevent uneven mellowing.

8. Regularly check all fixings to ensure none have come loose. Re-tighten if necessary.

9. Avoid sharp items such as a screwdriver or any pointy tools.

10. Dispose of all packaging carefully and responsibly - recycle where possible.

Parts list



P-3-16
V-1.0

Parts list










Before you begin building you Mila 2 Door Wardrobe,please take a moment to read through the instructions and make sure that you have all the relevant parts listed on the parts check list.

Part Number	Part Description	Quantity	Box No
①	Top Panel	1pc	Box 1
②	Left Side Panel	1pc	Box 2
③	Right Side Panel	1pc	Box 2
④	Bottom Panel	1pc	Box 1
⑤	Rounded Corners	2pcs	Box 1
⑥	Back Panel	1pc	Box 2
⑦	Shelf	1pc	Box 1
⑧	Support Rail	1pc	Box 1
⑨	Back Panel	3pcs	Box 2


Part Number	Part Description	Quantity	Box No
⑩	Back Rail	2pcs	Box 1
⑪	Back Rail	1pc	Box 1
⑫	Leg Rail	2pcs	Box 1
⑬	Leg Rail	3pcs	Box 1
⑭	Left Door	1pc	Box 2
⑮	Right Door	1pc	Box 2
⑯	Clothes Rail	1pc	Box 1


Fittings

Please check you have all the fittings listed below with your product in box 1.

A  M6*35mm Bolt 58pcs+5pcs extra	B  15*10mm Cam Lock 58pcs+5pcs extra	C  8*30mm Dowel 22pcs+2pcs extra	D  M4*40mm Screw 6pcs	E  M4*14mm Screw 4pcs
F  Wall Bracket 2pcs	G  M3*16mm Screw 36pcs+3pcs	H  Plastic Buckle 32pcs+3pcs	I  M7*40mm Screw 6pcs	J  Wall Plug 2pcs
K  Handle 2pcs	L  M4*18mm Bolt 2pcs	M  Clothes Tray 2pcs	N  M3.5*14mm Screw 52pcs+5pcs	O  Allen Key 1pc
P  Pad 6pcs	Q  Hinge 8pcs	R  M4*50mm Screw 3pcs	S  Magnet 2pcs	T  Metal plate 4pcs
U  M3*12mm Screw 4pcs				


1.Assemble wall bracket to the board.





A	M	N
		
M6*35mm Bolt	Clothes Tray	M3.5*14mm Screw
20pcs	2pcs	4pcs


P-6-16
V-1.0


2. Attach parts to the boards.



A

M6*35mm Bolt
14pcs
R

M4*50mm Screw
3pcs

3.







B
15*10mm Cam Lock
10pcs
C
8*30mm Dowel
3pcs


P-7-16
V-1.0


4.



5.







B	
	
15*10mm Cam Lock	
10pcs	
C	
	
8*30mm Dowel	
3pcs	


P-8-16
V-1.0


6.





D	O
	
M4*40mm Screw	Allen Key
4pcs	1pc
C	I
	
8*30mm Dowel	M7*40mm Screw
4pcs	6pcs

7.








B	A
	
15*10mm Cam Lock	M6*35mm Bolt
12pcs	12pcs




P-9-16
V-1.0


8.





B	C	P
		
15*10mm Cam Lock	8*30mm Dowel	Pad
14pcs	4pcs	6pcs





9.












G	S
	
M3*16mm Screw	Magnet
2pcs	1pc


A	B	C	E	F
				
M6*35mm Bolt	15*10mm Cam Lock	8*30mm Dowel	M4*14mm Screw	Wall Bracket
12pcs	6pcs	4pcs	4pcs	2pcs


P-10-16
V-1.0


10.




11.






B	C
	
15*10mm Cam Lock	8*30mm Dowel
6pcs	4pcs


G	S
	
M3*16mm Screw	Magnet
2pcs	1pc

P-11-16
V-1.0


12.



G


M3*16mm Screw
32pcs
H

Plastic Buckle
32pcs

13.



M
Clothes Tray
2pcs


14.



U				
M3*12mm Screw				
4pcs				
K	L	N	Q	T
Handle	M4*18mm Bolt	M3.5*14mm Screw	Hinge	Metal plate
2pcs	2pcs	16pcs	8pcs	4pcs

P-13-16
V-1.0

15.



N

M3.5*14mm Screw
32pcs

16.

WARNING: Open and close the doors to make sure they are aligned and shut correctly. If necessary, adjust the screws and bolts for a good fit.

1




Figure 1: Adjust these 4 screws to adjust the up and down direction of the door.

2




Figure 2: Adjust the bolt to adjust the front and rear direction of the door.

3






Figure 3: Adjust the bolt to adjust the left and right direction of the door.

17.


1:




2:





3:



4:





D	J
	
M4*40mm Screw	Wall Plug
2pcs	2pcs

P-16-16
V-1.0