

DUSK.COM

LIVING I BEDROOM I DINING


Range Name : Mila
Box1Dimension :W101xD47xH30cm
Product Dimension : W80xD40xH100cm

4 Drawer Tall Chest





Up to 60 minute sassembly time



Two person assembly



Electric screwdriver prohibited

This product is intended for domestic use only,not for commercial purposes.

P-1-14
V-1.0

IMPORTANT

ASSEMBLY TIP

Before you begin, it's best to identify all of the parts and fittings to build your Mila 4 Drawer Tall Chest frame. We advise laying these out on the floor to check you have everything, and to familiarise yourself with all of the parts and fittings before building.

TOP TIP

We recommend that you assemble the Mila 4 Drawer Tall Chest in the room you'd like it to be located. This will help prevent any risk of damage to the frame whilst moving it.

SAFETY AND CARE

It's important to ensure children and animals are kept away from the assembly area, as there are small components used in this product which could present a choking hazard. All plastic and wrapping materials should also be kept away from children and animals to prevent any risk of suffocation.

HELP AND SUPPORT

Please contact our customer service team on 0113 519 0311 if you have any questions or issues with your purchase.

RECYCLING

Please ensure that packaging is disposed of in a safe and environmentally friendly way, and recycle where possible. Please keep your assembly instructions safe to refer back to in the future.

CARE AND MAINTENANCE:

1. Only clean using a damp cloth, do not use bleach or abrasive cleaners as they may damage the finish over time.

2. Do not use a very wet cloth or allow any liquid to contact with the veneer for a long period of time. Wipe any spillage immediately. Absorption can cause wood to warp or finishes to de-laminate.

3.Do not scrub or rub the surface when cleaning.

4. Do not drag the Mila 4 Drawer Tall Chest when moving, lift it off the floor instead.

5. Use a placemat or a coaster when putting hot items (e.g. hot drinks and dishes) on the wood surface.

6. It is not recommended to place the item next to sources of heat such as radiators, fires or directly exposed to sunlight. This may cause the wood to crack, split or fade due to the heat and humidity.


7. Wood will mellow and change colour over time, we recommend that ornaments and items placed on the surface to be moved regularly to prevent uneven mellowing.


8. Regularly check all fixings to ensure none have come loose. Re-tighten if necessary.

9. Avoid sharp items such as a screwdriver or any pointy tools.

10. Dispose of all packaging carefully and responsibly - recycle where possible.

Parts list





Parts list



Before you begin building you Mila 4 Drawer Tall Chest,please take a moment to read through the instructions and make sure that you have all the relevant parts listed on the parts check list.


Part Number	Part Description	Quantity	Box No
①	Top Panel	1pc	Box 1
②	Left Side Panel	1pc	Box 1
③	Right Side Panel	1pc	Box 1
④	Bottom Panel	1pc	Box 1
⑤	Rounded Corners	2pcs	Box 1
⑥	Rounded Corners	2pcs	Box 1
⑦	Front Rail	3pcs	Box 1
⑧	Back Panel	1pc	Box 1
⑨	Back Rail	1pc	Box 1
⑩	Back Panel	1pc	Box 1
⑪	Back Rail	1pc	Box 1
⑫	Leg Rail	2pcs	Box 1
⑬	Leg Rail	2pcs	Box 1



Number	Part Description	Quantity	Box No
⑭	Drawer Front Panel	4pcs	Box 1
⑮	Drawer Left Side With Slide	4pcs	Box 1
⑯	Drawer Back Panel	4pcs	Box 1
⑰	Drawer Right Side With Slide	4pcs	Box 1
⑱	Drawer Bottom Panel	4pcs	Box 1
⑲	Support Rail	4pcs	Box 1

Fittings



Please check you have all the fittings listed below with your product in box 1.

A	B	C	D	E
				
M6*35mm Bolt	15*10mm Cam Lock	8*30mm Dowel	M3*16mm Screw	M4*12mm Screw
72pcs+7pcs extra	72pcs+7pcs extra	30pcs+3pcs extra	12pcs+1pc	2pcs

F	G	H	I	J
				
M4*35mm Screw	Handle	M4*18mm Bolt	Wall Plug	Wall Bracket
29pcs+2pcs	4pcs	4pcs	2pcs	2pcs


K	L
	
Foot Pad	Back Panel Clip
4pcs	12pcs+1pc


Pre-assembled Fittings


R-1	R-2	S
		
300mm Slide	300mm Slide	M3*12mm Screw
8pcs	8pcs	48pcs


1. Attach parts to the boards.


x2











A

M6*35mm Bolt
28pcs

2. Attach parts to the boards.







B	C
	
15*10mm Cam Lock	8*30mm Dowel
4pcs	4pcs


P-6-14
V-1.0


3.Assemble wall bracket to the board.




A

M6*35mm Bolt
14pcs

4.Assemble boards to the frame.






B


15*10mm Cam Lock
7pcs
C

8*30mm Dowel
3pcs


P-7-14
V-1.0

5.



6.






B


15*10mm Cam Lock
7pcs
C


8*30mm Dowel
3pcs




P-8-14
V-1.0

7.Assemble boards to the frame.











A	E
	
M6*35mm Bolt 10pcs	M4*12mm Screw 2pcs
B	**J**
	
15*10mm Cam Lock 12pcs	Wall Bracket 2pcs
C	
	
8*30mm Dowel 8pcs	


8.








B	F
	
15*10mm Cam Lock 6pcs	M4*35mm Screw 3pcs
C	
	
8*30mm Dowel 4pcs	

9.




B

15*10mm Cam Lock
10 pcs
C

8*30mm Dowel
4 pcs
K

Foot Pad
4 pc





10.



P-10-14
V-1.0

11.






B	
	15*10mm Cam Lock
	6pcs
C	
	8*30mm Dowel
	4pcs

12.


x4




A	H
M6*35mm Bolt	M4*18mm Bolt
20pcs	4pcs


F
M4*35mm Screw
24pcs


G
Handle
4pcs



13.









B

15*10mm Cam Lock
20pcs


14.




D

M3*16mm Screw
12pcs
L

Back Panel Clip
12pcs


15.




F

M4*35mm Screw
2pcs
I

Wall Plug
2pcs


1:




2:




3:




4:




16.







When installing the drawer into the cabinet, align the slide rails properly first, then push it gently — do not force it in.
Make sure to move the metal sheet to the outermost position.



18. How to take apart a drawer

1. Pull out the drawer until the plastic clips on the rail are visible.
2. Push the plastic clip up on the left side and down on the right side. Note that the clips on the left and right rails face opposite directions at the same time.
3. While pressing the clips at the same time, pull out the drawer to separate the rails.

