

DUSK.COM



LIVING | BEDROOM | DINING

Range Name : EVIE


Box 1 Dimensions : W75.5xD55xH19.5cm

Product Dimension : W50xD40xH63.5cm

Evie Bedside



Up to 30 minutes
assembly time



Two person
assembly

This product is intended for domestic use only, not for commercial purposes.

P-1-10
V-2.0

IMPORTANT

ASSEMBLY TIP

Before you begin, it's best to identify all of the parts and fittings to build your Evie Bedside frame. We advise laying these out on the floor to check you have everything, and to familiarise yourself with all of the parts and fittings before building.

TOP TIP

We recommend that you assemble the Evie Bedside in the room you'd like it to be located. This will help prevent any risk of damage to the frame whilst moving it.

SAFETY AND CARE

It's important to ensure children and animals are kept away from the assembly area, as there are small components used in this product which could present a choking hazard. All plastic and wrapping materials should also be kept away from children and animals to prevent any risk of suffocation.

HELP AND SUPPORT

Please contact our customer service team on 0113 519 0311 if you have any questions or issues with your purchase.

RECYCLING

Please ensure that packaging is disposed of in a safe and environmentally friendly way, and recycle where possible. Please keep your assembly instructions safe to refer back to in the future.


CARE AND MAINTENANCE:

1. Only clean using a damp cloth, do not use bleach or abrasive cleaners as they may damage the finish over time.
2. Do not use a very wet cloth or allow any liquid to contact with the veneer for a long period of time. Wipe any spillage immediately. Absorption can cause wood to warp or finishes to de-laminate.
3. Do not scrub or rub the surface when cleaning.
4. Do not drag the Evie Bedside when moving, lift it off the floor instead.
5. Use a placemat or a coaster when putting hot items (e.g. hot drinks and dishes) on the wood surface.
6. It is not recommended to place the item next to sources of heat such as radiators, fires or directly exposed to sunlight. This may cause the wood to crack, split or fade due to the heat and humidity.
7. Wood will mellow and change colour over time, we recommend that ornaments and items placed on the surface to be moved regularly to prevent uneven mellowing.
8. Regularly check all fixings to ensure none have come loose. Re-tighten if necessary.
9. Avoid sharp items such as a screwdriver or any pointy tools.
10. Dispose of all packaging carefully and responsibly - recycle where possible.

Parts list
















Before you begin building your Evie Bedside, please take a moment to read through the instructions and make sure that you have all the relevant parts listed on the parts check list.

Part Number	Part Description	Quantity	Box No
①	Left Side Panel With Slide	1pc	Box 1
②	Right Side Panel With Slide	1pc	Box 1
③	Bedside Top	1pc	Box 1
④	Back Panel	1pc	Box 1
⑤	Bottom Panel	1pc	Box 1
⑥	Leg	4pcs	Box 1
⑦	Drawer Front	2pcs	Box 1
⑧	Drawer Left Side With Slide	2pcs	Box 1
⑨	Drawer Right Side With Slide	2pcs	Box 1
⑩	Drawer Back Side	2pcs	Box 1
⑪	Drawer Bottom	2pcs	Box 1






Fittings





Please check you have all the fittings listed below with your product in box 1.

A  M6*35mm Bolt 12pcs+1pc extra	B  Ø15x9.5mm Cam Lock 12pcs+1pc extra	C  Ø8x30mm Dowel 8pcs+1pc extra	D  M3.5*12mm Screw 4pcs	E  M3*14mm Screw 4pcs
F  M4*35mm Screw 9pcs+1pc extra	G  M5*40mm Screw 6pcs	H  3mm Allen Key 1pc	I  15x9mm Plastic Buckle 4pcs	J  Handle 2pcs
K  M4*14mm Screw 17pcs+1pc extra	L  Wall Bracket 1pc	M  Ø6x30mm Wall Plug 1pc	N  Cover 8pcs+1pc extra	O  Slide pre assembled 4pcs




Pre-assembled Fittings.

O1  Slide pre assembled 4pcs	O2  Slide pre assembled 4pcs	D  M3.5*12mm Screw 20pcs
---	---	---


1. Attach Parts to the bedside top.







2. Attach left and right side panels to the bedside top.




3.Assemble the back panel.




4.Attach bottom panel to the Frame.





5. Attach legs to the Frame.





K

M4*14mm Screw 16pcs


6. Assemble the Drawers.





B

Ø15x9.5mm Cam Lock 8pcs

A

M6*35mm Bolt 8pcs

D

M3.5*12mm Screw 4pcs


F

M4*35mm Screw 8pcs

J

Handle 2pcs


N

Cover 8pcs

x 2


7. Assemble the drawers in the Bedside.





8. Manually adjust the frame slightly to ensure the drawers are in the correct position, even and parallel before attaching the plastic buckles.




9. Attach the plastic Buckles.







<div data-bbox="117 886 166 936">E</div> <div data-bbox="219 936 277 982"></div> <div data-bbox="117 1040 360 1111">M3*14mm Screw 4pcs</div>	<div data-bbox="381 886 431 936">I</div> <div data-bbox="484 936 525 982"></div> <div data-bbox="381 1040 624 1111">15x9mm Plastic Buckle 4pcs</div>
---	---

10. Take out the drawer.



11. Fix the L-shaped Bracket to the wall.



12. Assemble the drawers in the Bedside.

