




## Willow Storage Dressing Table



Up to 45 minutes  
assembly time



Two person  
assembly

This product is intended for domestic use only, not for commercial purposes.

# **IMPORTANT**

## **ASSEMBLY TIP**

Before you begin, it's best to identify all of the parts and fittings to build your storgae dressing table frame. We advise laying these out on the floor to check you have everything, and to familiarise yourself with all of the parts and fittings before building.

## **TOP TIP**

We recommend that you assemble the storgae dressing table in the room you'd like it to be located. This will help prevent any risk of damage to the frame whilst moving it.

## **SAFETY AND CARE**

It's important to ensure children and animals are kept away from the assembly area, as there are small components used in this product which could present a choking hazard. All plastic and wrapping materials should also be kept away from children and animals to prevent any risk of suffocation.

## **HELP AND SUPPORT**

Please contact our customer service team on 0113 519 0311 if you have any questions or issues with your purchase.


## **RECYCLING**

Please ensure that packaging is disposed of in a safe and environmentally friendly way, and recycle where possible. Please keep your assembly instructions safe to refer back to in the future.

## **CARE AND MAINTENANCE:**

1. Only clean using a damp cloth, do not use bleach or abrasive cleaners as they may damage the finish over time.
2. Do not use a very wet cloth or allow any liquid to contact with the veneer for a long period of time. Wipe any spillage immediately. Absorption can cause wood to warp or finishes to de-laminate.
3. Do not scrub or rub the surface when cleaning.
4. Do not drag the storgae dressing table when moving, lift it off the floor instead.
5. Use a placemat or a coaster when putting hot items (e.g. hot drinks and dishes) on the wood surface.
6. It is not recommended to place the item next to sources of heat such as radiators, fires or directly exposed to sunlight. This may cause the wood to crack, split or fade due to the heat and humidity.
7. Wood will mellow and change colour over time, we recommend that ornaments and items placed on the surface to be moved regularly to prevent uneven mellowing.
8. Regularly check all fixings to ensure none have come loose. Re-tighten if necessary.
9. Avoid sharp items such as a screwdriver or any pointy tools.
10. Dispose of all packaging carefully and responsibly - recycle where possible.

## Parts list



# Parts list

Before you begin building your Willow Storage Dressing Table, please take a moment to read through the instructions and make sure that you have all the relevant parts listed on the parts check list.

| Part Number | Part Description       | Quantity | Box No |
|-------------|------------------------|----------|--------|
| ①           | Side Top               | 2 pcs    | Box 1  |
| ②           | Middle Top With Mirror | 1 pc     | Box 1  |
| ③           | Back Panel             | 1 pc     | Box 1  |
| ④           | Left Side Panel        | 1 pc     | Box 1  |
| ⑤           | Right Side Panel       | 1 pc     | Box 1  |
| ⑥           | Middle Panel           | 2 pcs    | Box 1  |
| ⑦           | Middle Panel           | 1 pc     | Box 1  |
| ⑧           | Middle Panel           | 1 pc     | Box 1  |
| ⑨           | Door                   | 2 pcs    | Box 1  |




















| Part Number | Part Description | Quantity | Box No |
|-------------|------------------|----------|--------|
| ⑩           | Front Panel      | 1 pc     | Box 1  |
| ⑪           | Bottom Panel     | 1 pc     | Box 1  |
| ⑫           | Support Tube     | 1 pc     | Box 1  |
| ⑬           | Support Tube     | 1 pc     | Box 1  |
| ⑭           | Left Leg         | 1 pc     | Box 1  |
| ⑮           | Right Leg        | 1 pc     | Box 1  |
| ⑯           | Reinforced Tube  | 2 pcs    | Box 1  |
| ⑰           | Leg Support      | 1 pc     | Box 1  |

## Pre-assembled Parts.



|   |                      |      |       |
|---|----------------------|------|-------|
| ② | Mirror Pre-assembled | 1 pc | Box 1 |
|---|----------------------|------|-------|

# Fittings



Please check you have all the fittings listed below with your product in Box 1.

|  |  |   |   |  |  |
|--|--|---|---|--|--|
| <div>A</div>  <div>M6*12mm Bolt<br/>12pcs+2pcs extra</div>  | <div>B</div>  <div>M6*20mm Bolt<br/>4pcs</div>              | <div>C</div>  <div>M6*35mm Bolt<br/>8pcs+1pc extra</div> | <div>D</div>  <div>M6*35mm Bolt<br/>16pcs+3pcs extra</div> | <div>E</div>  <div>Ø15*12mm Cam Lock<br/>16pcs+3pcs extra</div> | <div>F</div>  <div>M3.5*14mm Screw<br/>40pcs+7pcs extra</div> |
| <div>G</div>  <div>M7*48mm Screw<br/>18pcs+3pcs extra</div> | <div>H</div>  <div>Ø8*30mm Dowel<br/>24pcs+4pcs extra</div> | <div>I</div>  <div>Handle<br/>2pcs</div>                 | <div>J</div>  <div>M4*20mm Bolt<br/>2pcs</div>             | <div>K</div>  <div>Allen Key<br/>1pc</div>                      | <div>L</div>  <div>Sticker<br/>6pcs+1pc extra</div>           |
| <div>M</div>  <div>Hinge<br/>4pcs</div>                     | <div>N</div>  <div>Hinge<br/>2pcs</div>                     | <div>O</div>  <div>Lid Support Hinge<br/>1pc</div>       | <div>P</div>  <div>M4*14mm Screw<br/>2pcs</div>            | <div>Q</div>  <div>M4*35mm Screw<br/>2pcs</div>                 | <div>R</div>  <div>Ø6*30mm Wall Plug<br/>2pcs</div>           |
| <div>S</div>  <div>Strip<br/>2pcs</div>                     |  |   |   |  |  |


## 1. Attach the Bolts to the Panels.



## 2. Attach the Back Panel to the Side Panels.




### 3. Attach the Front Panel to the Middle Panels.



|   |                   |
|---|-------------------|
| E |                   |
|   | Ø15*12mm Cam Lock |
|   | 4pcs              |


### 4. Attach the Bolts to the Middle Panels.





|   |              |
|---|--------------|
| B |              |
|   | M6*20mm Bolt |
|   | 4pcs         |


|   |           |
|---|-----------|
| K |           |
|   | Allen Key |
|   | 1pc       |


## 5. Tighten the Screws into the Frame.





|   |  |
|---|--|
| <b>G</b><br> | <b>K</b><br> |
| M7*48mm Screw<br>4pcs   | Allen Key<br>1pc   |

## 6. Attach the Bottom Panel onto the Frame.






|   |
|---|
| <b>K</b><br> |
| Allen Key<br>1pc  |

|   |
|---|
| <b>H</b><br> |
| Ø8*30mm Dowel<br>12pcs  |


|   |
|---|
| <b>G</b><br> |
| M7*48mm Screw<br>14pcs  |



## 7. Attach the Hinges to the Doors.



|   |   |
|---|---|
| <b>F</b>  | <b>M</b>  |
|  |  |
| M3.5*14mm Screw   | Hinge   |
| 8pcs  | 4pcs  |


## 8. Attach the Doors to the Bottom Panel and tighten the Screws fully.




|   |   |
|---|---|
| <b>F</b>  | <b>K</b>  |
|  |  |
| M3.5*14mm Screw   | Allen Key   |
| 16pcs   | 1pc   |




## 9. Attach the Bolts to the Side Tops.





x2

|   |
|---|
| D   |
|  |
| M6*35mm Bolt  |
| 8pcs  |




## 10. Attach the Side Tops onto the Frame.






|   |
|---|
| H   |
|  |
| Ø8*30mm Dowel   |
| 12pcs   |

|   |
|---|
| E   |
|  |
| Ø15*12mm Cam Lock   |
| 8pcs  |


## 11. Attach the Stickers onto the Cam Locks and the Bolts.





## 12. Assemble the Handles.





### 13. Attach the Hinges to the Middle Top.




|   |   |
|---|---|
| <b>F</b><br> | <b>N</b><br> |
| M3.5*14mm Screw   | Hinge   |
| 4pcs  | 2pcs  |

### 14. Attach the Middle Top to the Back Panel.






|   |
|---|
| <b>F</b><br> |
| M3.5*14mm Screw   |
| 8pcs  |

## 15. Adjust the Doors.





## 16. Attach the Lid Support Hinge to the Frame.




|   |   |
|---|---|
| <b>F</b><br> | <b>O</b><br> |
| M3.5*14mm Screw<br>4pcs   | Lid Support Hinge<br>1pc  |


## 17. Adjust tightness to adjust the support force.





|           |  |
|-----------|--|
| K         |  |
| Allen Key |  |
| 1pc       |  |

## 18. Assemble the Legs.




|           |   |
|-----------|---|
| K         |  |
| Allen Key |   |
| 1pc       |   |

|              |   |
|--------------|---|
| C            |  |
| M6*35mm Bolt |   |
| 4pcs         |   |

|              |   |
|--------------|---|
| A            |  |
| M6*12mm Bolt |   |
| 8pcs         |   |


## 19. Attach the Reinforced Tubes to the Leg Frame.

|   |                      |
|---|----------------------|
| K | Allen Key<br>1pc     |
| A | M6*12mm Bolt<br>4pcs |








## 20. Attach the Legs onto the Frame.

|   |                      |
|---|----------------------|
| C | M6*35mm Bolt<br>4pcs |
| K | Allen Key<br>1pc     |






## 21. Attach the Strips to the Bottom Panel.

|   |   |
|---|---|
| S |  |
|   | Strip   |
|   | 2pcs  |
| P |  |
|   | M4*14mm Screw   |
|   | 2pcs  |



## 22. Fix the Strips to the wall.



|   |   |
|---|---|
| R |  |
|   | Ø6*30mm Wall Plug   |
|   | 2pcs  |
| Q |  |
|   | M4*35mm Screw   |
|   | 2pcs  |

